CLEANING AND CARE OF CENTRIFUGES

Regular cleaning and maintenance ensures the long lifespan of your Hettich centrifuge. Reduce unnecessary repair costs by following these recommendations.

We suggest setting a regular time daily or weekly – only 15 minutes per week ensure that the failure probability of your centrifuge is significantly reduced. This poster does not replace the operating manual.

PREVENTIVE ACTIONS



Switch off the device and disconnect the centrifuge from the power supply.

Step 2

For cleaning, use appropriate PPE (personal protective equipment, e.g. rubber gloves).

All you need for cleaning is a mild detergent with a pH value of 5-8 or a 70% alcohol solution and slightly damp paper towels.

Step 4

Clean the surface of the device (housing).





he correct rotor position of the

GREASE

Lubricate (using Hettich

grease no. 4051) the

motor shaft and rotor

trunnions or buckets.

Please note: Excess

grease in the centri-

fuge chamber must

be removed.

SETUP AND TEST RUN

Replace the accessories in reverse order and perform a test run without samples.

CYCLE: WEEKLY

separately.

CLEANING OF ACCESSORIES

REMOVING THE ACCESSORIES

Remove the centrifuge accessories

such as rotor, buckets and inserts

Clean the accessories and pay attention to the rotor trunnions and of the buckets.



CLEANING THE CENTRIFUGE CHAMBER

Clean the centrifuge chamber and the motor shaft thoroughly.



VISUAL INSPECTION

Check the accessories for corrosion, cracks or other damage.



For service questions you can contact us via: